

Signal Timer with 4 Outputs USER Manual

Version: Nov_2025

TABLE of CONTENTS:

Operating Modes Overview

Page 2

Programming the Relay/Output Sequence

Table of Valid Sequence Commands

Advanced Topics / MQTT & Home Automation Control

Trouble Shooting

Firmware Upgrade

Wiring Diagram / Schematic

Operating Modes Overview:

First: What is a 'Sequence' ?

Simply put the sequence is a comma separated list of output commands. The default 'Sequence' loaded into the Signal Timer is "1,2,3,4". This means that Output#1 is turned ON first. Then Output#2 will be turned ON. (Note: Output#1 is turned OFF, when Output#2 is turned ON). This is followed by Outputs #3 & #4. Once the end of the sequence is reached, the Signal Timer starts back at the first step in the sequence. The time between each step is called 'Dwell'. The default 'Dwell' is 10 seconds. (Note: during the Sequence Review & Edit mode the dwell is fixed at 4 seconds. This allows for easy review of the current sequence) The Sequence & Dwell are easy to change. See ***Programming the Relay/Output Sequence***

Sequence Review & Edit mode

The Signal Timer with 4 Outputs has several modes of operation. The ***Sequence Review & Edit mode*** is in effect when power is first applied to the device. It starts about 5 seconds after power is applied. The Blue ACTIVITY LED will flash ON & OFF about twice a second. During this mode each step in the defined Sequence is output for four seconds. When the end of the Sequence is reached the Signal Timer starts back at the first step in the Sequence. This mode is in effect for about 90 seconds, During this time the Sequence can be changed. See ***Programming the Relay/Output Sequence***

Sequence Playback mode

Once the Sequence Review & Edit mode is complete (~90 seconds) The Signal Timer starts the sequence playback mode. The sequence repeats until power is turned OFF. What is a sequence? See: ***First: What is a 'Sequence' ?*** During Sequence playback Manual Control is only available if you have programmed your home's Wifi network into the Signal Timer. See: [WIP]

Operating Modes Overview: (continued)

Manual Control

Manual control is available if you have programmed your home's Wifi network into the Signal Timer. See: [WIP]. Access the Signal Timer's web page & control the Signal Timer's Outputs. (See: picture of web page)

The screenshot shows a web interface titled "ARM-C0B0F1" in large blue letters. Below the title, there are three sections for manual control:

- Sequence:** 1,2,3,4. Below this is a "New:" label followed by a text input field and a "Submit" button.
- Dwell:** 10 seconds. Below this is a "New:" label followed by a text input field and a "Submit" button.
- Output Control:** A "Submit" button is next to the label. Below it are five radio button options: RLY#1, RLY#2, RLY#3, RLY#4, and ALL OFF.

Below the radio buttons, there are two more sections:

- Searchlight:** Three radio button options: RED, YELLOW, and GREEN.
- Semaphore:** Three radio button options: STOP, APPROACH, and CLEAR.

At the bottom of the main content area, the text "SigTmr4rly|Nov_2025" is displayed.

The bottom of the screen features a dark navigation bar with a home icon, a lock icon, and the IP address "192.168.4.1".

[User wiring options]

